

TYRE-CHANGERS - BIKES & MOTORCYCLES

For tyre specialists, servicing motorcycles, scooters and ATV tyres.



Sturdy, user friendly and problem solving tyre changer to help best professionals in the field.

5116 BIKE



SEMI-AUTOMATIC SWING ARM TYRE CHANGER FOR MOTORCYCLES, SCOOTERS & ATV TYRES



Kit of 4 motorcycles adaptors with wider clamps, oversize/ standard height (optional).

Reinforced Chassis.
Robust vertical tower.



Fitting head designed for both standard and low profiled tyre applications.

- Plastic protections on fitting head to avoid any damage to alloy rim.
- Four motorcycle clamping jaws adjustable to 4 different positions: 6"-13", 10"-17", 14"-21", 17"-24".
- Tabletop thickness 12 mm, specially designed for motorcycle wheels.
- Two powerful clamping cylinders provide uniform clamping pressure.
- Tyre inflation by pedal (optional).
- Tyre inflating gauge (optional).

BMW Motorrad approved version is available through official BMW channels.





Available in:

Blue Trim
BlackTrim
Red Trim

Semiautomatic

3 control pedals, fixed vertical tower, swinging horizontal arm and operating arm with manual lowering and locking by hand-lever.

Swinging horizontal arm with ø 36 mm operating arm.





Discover on our website!



5 YEAR WARRANTY ON GEARBOX



Suitable for **PRESS ARM ECO** additional pneumatic helper tower to ease mounting operations of low profiled and UHP tyres (optional):





effect Cylinder ø 200 mm.

Designed, built and engineered in Italy.



PEDAL INFLATION SET. Insalled on the side of the tyre changer, provides inflation system on board the tyre changer, activated by pedal (optional).



STANDARD FEATURES

Rim clamping from outside	6" - 24"
Max. tyre diameter	1010 mm (39")
Max. tyre width	240 mm (9,5")
Bead breaker cylinder force at 10 Bar	30800 N
Operating pressure	10 bar (145 Psi)
Power supply	400V - 3 ph / 220V - 1 ph
Motor power	0,55 kW (3 ph)
Rotation speed	7 rpm
Pre-set tyre inflating pressure	3,5 bar (50 Psi)
Net weight	175 kg
Max. overall dimensions	1110x960x1710 mm

STANDARD ACCESSORIES



- Bead lifting lever Lube paste bucket and Brush Plastic protectors for mounting/demounting tool (3 front + 3 rear) 2 Protectors for bead breaker shovel Lubricator + Pressure regulator
- Bucket support